


OPERATION MANUAL

YANMAR

YANMAR DIESEL ENGINE 6LY(M)-STE



**Be sure to read this manual for safe and proper operation.
Store this manual carefully after use.**



ISO 9001 Certified

**Thank you very much for selecting the
6LY(M)-STE
YANMAR DIESEL ENGINE.**

This manual includes all the information necessary to operate, check and service your YANMAR engine as well as important instructions for safety precautions.

Before starting up your new engine, we request that you carefully read this manual to ensure the proper operation of the engine. If you have any questions, please consult your nearest dealer or sales agency.

YANMAR OPERATION MANUAL for 6LY(M)-STE

Thank you for purchasing a Yanmar product.

This Operation Manual tells you how to operate and service your new Yanmar engine. Please read it before using the engine to insure proper handling and operation. Follow the instructions carefully to keep your engine in the best running condition. If you have any question concerning this manual, or any suggestions, please contact your nearest Yanmar dealer.

This Operation Manual deals with the main points for operation of the 6LY(M)-STE.

In order to insure safe working conditions, be sure to read the precaution sections for safe operation of your engine.

Pay special attention to statements preceded by the following words:

 **Warning:**

Indicates a strong possibility of severe personal injury or loss of life if instructions are not followed.

 **Caution:**

Indicates a possibility of personal injury or equipment damage if instructions are not followed.

Note:

Gives helpful information.

If a problem should arise, or if you have any questions about the engine, consult an authorized Yanmar dealer.

 **Warning:**

The Yanmar 6LY(M)-STE engine is designed to give safe and dependable service provided that it is operated according to instructions.

Read and understand this Operation Manual before operating your engine. Failure to do so could result in personal injury or equipment damage.

TIPS ON SAFETY

Warning:

1. PREVENTING FIRES

Never add fuel to the fuel tank while the engine is running. Wipe away all fuel spills with a clean cloth. Keep gasoline, Kerosene, matched, other explosives and inflammables away from the engine, since the temperature around the exhaust manifold and exhaust mixing elbow are very high during operation.

2. PREVENTING EXHAUST GAS INHALATION

- Exhaust gas contains poisonous carbon monoxide.
- Never use the engine in poorly ventilated conditions, provide proper ventilation so that people and animals will not be affected.

3. PREVENTING BURNS

- Never touch the exhaust manifold, exhaust mixing elbow, turbocharger or engine body while the engine is running or hot.

4. OTHER SAFETY TIPS

- Know how to stop the engine quickly and understand operation of all the controls.
Never permit anyone to operate the engine without proper instructions.
- Do not operate under the influence of alcohol.
- Keep children and pets away from the engine when it is in operation.
- Keep away from rotating parts while the engine is running.
- When the engine is coupled with a machine, be sure to provide suitable covers for the belt, coupling and other dangerous parts.
- Work according to the rules and regulations of work area. When working with others, be sure to maintain good communication with everyone else.
- Use correct tools and equipment.

5. WHEN CHARGING THE BATTERY

- Battery electrolyte contains sulphuric acid. Protect your eyes, skin and clothing. In case of contact, flush thoroughly with water and get prompt medical attention, especially if your eyes are affected.
- Batteries generate hydrogen gas which can be highly explosive. Do not smoke or allow flames or sparks near a battery, especially during charging.
- Charge the battery in a fully ventilated place.


CONTENTS

1. IDENTIFICATION OF IMPORTANT PARTS	1
2. ENGINE SPECIFICATIONS	3
3. PRECAUTIONS	4
4. FUEL AND LUBE OIL	9
4-1 Selection and Handling of Fuel	9
4-2 Selection of Lube Oil	9
5. INITIAL OPERATION OF NEW ENGINE	10
5-1 Fuel Supply	10
5-2 Lube Oil Supply	10
5-3 Cooling Water Supply for Fresh Water Tank	11
5-4 Tightening Drain Cock of Seawater System	12
5-5 Bleeding Air from Fuel System	12
5-6 Lubricating Each Section	12
5-7 External Inspection	12
5-8 Checking Operation of Remote Control Unit	13
5-9 Starting Engine for the First Time	13
5-10 Checking Operation of Gauges (Standard Tanmar Panel)	13
5-11 Checking Alarm Devices (Standard Tanmar Panel)	14
5-12 Re-checking Starting Engine for the First Time	14
6. OPERATION	15
6-1 Starting	15
6-2 Cautions Required Immediately After Starting	16
6-3 Cautions Required During Operation	16
6-4 Stopping	17
7. HANDLING THE MARIN GEAR	19
7-1 Handling Precautions	19
7-2 Handling the Emergency Bolts	19
7-3 Checking and Adjusting the Marine Gear (Yanmar Marine Gear)	20


8. PERIODICAL CHECKS AND SERVICE	21
8-1 Fuel Oil System	24
8-2 Lube Oil System	26
8-3 Cooling Water System (Seawater and Fresh Water)	28
8-4 Lubrication of External Parts	31
8-5 Checking the Marine Gear (Only for 6LY-STE)	31
8-6 Adjusting the Remote Control Cable	32
8-7 Checking the Electrical Parts	32
8-8 Handling of Electrical Bilge Pump (Standard Yanmar Model)	34
8-9 Checking the Turbocharger	37
 9. EASY TROUBLESHOOTING GUIDE	 38
9-1 Air Is Mixed in Fuel System	38
9-2 Pressures of Engine Lube Oil Is Abnormal	38
9-3 Fresh Water Temperature Is Abnormally High	39
9-4 Marine Gear Oil Pressure Is Abnormal (Yanmar Marine Gear)	39
 10. SYSTEM DIAGRAMS	 40
1) Fuel Oil System Diagram	40
2) Cooling Water System Diagram	41
3) Lube Oil System Diagram	42
4) B2-type Instrument Panel	43

1. IDENTIFICATION OF IMPORTANT PARTS

Operating side



Non-operating side



2. ENGINE SPECIFICATIONS

Item

Type			Vertical water-cooled 4-cycle diesel engine								
Model			6LY-STE			6LYM-STE					
No. of cylinders			6								
Con- tinuous rating output	Output rotational speed		213.3 KW (290 PS)/3100 rpm								
	Net average effective pressure		16.2 kg/cm ²								
Max. rating output	Output rotational speed		257.4 KW (350 PS)/3300 rpm								
	Net average effective pressure		18.4 kg/cm ²								
Idling speed			750 ± 25 rpm								
Combustion system			Direct injection								
Intake/exhaust valve system			2 intake valves and 2 exhaust valves								
Fuel injection timing			13° ± 1								
Reduction and revers- ing gear (clutch)	Hydraulic type	Model		KMH6A							
		Reduc- tion ratio	Ahead	1.58	1.92	2.26	Clutch less				
Direc- tion of rotation	Astern		1.58	1.92	2.26						
	Crankshaft		Counterclockwise when viewed from flywheel side								
	Propeller shaft		Counterclockwise when viewed from stern side								
Lubrication system			Totally enclosed and forced lubrication system with gear pump								
Lube oil capacity	Oil pan(Full/Effective)		20 l / 8 l								
	Clutch(Full/Effective)		4.0 l / 0.3 l								
Cooling system			Fresh water cooling								
Fresh water volume	Engine		24 l								
	Subtank		0.8 l								
Cooling water deliv- ery (at engine speed of 3200 rpm)		Fresh water	≥17000 l /Hr								
		Seawater	≥8300 l /Hr								
Starter system			Electric starting								
Electric- al equip- ment	Starting motor		DC12V 2.5kW								
	Alternator (generator)		DC12V 80A								
Turbo- charger	Type		IHI Model RHC7W								
	Cooling system		Water cooling								

3. PRECAUTIONS

To prolong the service life of your YANMAR engine, be sure to observe the following precautions.

No.	Precautions	Troubles Due Failure to Observe
1	Be sure to break-in the new YANMAR engine.	<p>The components of a new engine must wear in together, imposing undue load on the engine during this wear, may shorten the engine service life.</p> <p>Caution : Do not impose any undue load on the engine for at least 50 hours after installation and initial running of the engine. Be sure to operate the engine at 2500 rpm or lower.</p>
2	<p>(1)It is recommended that a diesel fuel oil (#2) and equivalent be used.</p> <p>(2)Be sure to properly drain the fuel filter, oil-water separator, and fuel tank. For draining procedures, see Sec. 8-1.</p> <p>(3)Replace the fuel filter element every 250 service hours.</p> <p>See Sec. 8-1 for details of replacement.</p>	<p>(1)If you use the engine in cold weather, use No. 3 special light oil. Use of any other fuel oil may result in frozen oil and cause stoppage of oil flow.</p> <p>(2)Be sure to use of cetane number 45 or more. Use of a cetane number less than 45 may deteriorate the combustion performance.</p> <p>Fuel oil mixed with water or moisture may cause failures to occur in the fuel injection pump and injection valve, and may significantly shorten the service life of the engine.</p> <p>If the filter element has been used for a long period of time without servicing, it will become clogged so that the flow rate of fuel oil will drop, causing engine trouble.</p>
3	<p>(1)Use lubricant complying to SAE J183 15W40 (Class CD) for engine.</p> <p>If oil of this grade is not available, contact nearest our dealer.</p> <p>(2)Use lubricant complying SAE #30 (Class CD) for clutch.</p> <p>If oil of this grade is not available, contact nearest our dealer.</p>	<p>Using an oil other than the one recommended may shorten the service life of the engine, due to, for example, piston ring sticking, seizure of pistons and liners, premature wear of moving parts, or other trouble.</p> <p>This oil should be used in the Yanmar KMH6A marine gear. If some other marine gear is supplied consult manufacturer's operation manual for correct oil type.</p>

No.	Precautions	Troubles Due to Failure to Observe
3	Be sure to change both the lube oil and filter element at the time intervals indicated on the right.	<p>(1) Lube oil change</p> <p>Engine side</p> <p>{ 1st change: At 50 service hrs 2nd and subsequent changes: Every 250 service hrs</p> <p>Clutch side</p> <p>{ 1st change: After 50 service hrs 2nd change: After 250 service hrs 3rd and subsequent changes: Every 1000 service hrs or every 5 or 6 months</p> <p>Replacement of filter element</p> <p>{ 1st replacement: After 50 service hrs 2nd and subsequent replacements: Every 250 service hrs</p> <p>Cleaning of clutch oil filter</p> <p>{ 1st washing: At 50 service hrs after overhauling or initial operation 2nd washing: At 250 service hrs after overhauling 3rd and subsequent washings: Every 1000 service hrs or every 5 or 6 month</p> <p>⚠ Caution 1: Using old lube oil may cause premature wear of each part, leading to serious trouble.</p> <p>⚠ Caution 2: Using the filter element for an excessively long period of operation will cause it to clog with dirt. This in turn will cause various problems such as low oil pressure, metal seizure, and entry of dirt between the metal parts, resulting in premature wear.</p> <p>⚠ Caution 3: The clogged clutch oil filter may cause reduction in hydraulic oil pressure, clutch slipping, or dirt attached to the metal parts or pump. This will result in the quick wear of the clutch.</p>
4	Important : Extra care should be taken when using fresh water.	
	Use tap water or clean rain water as fresh water.	⚠ Caution: If hard water such as that taken from a well is used, foreign deposits in the water will build up on the cooling water passage. As a result, the cooling performance will drop and the temperature of the cooling water will rises abnormally, causing seizure of pistons and liners.
	Be sure to add the antirust agent to the fresh water. For further details, see Sec. 8-3 #7).	Once the cooling water passage begins to corrode, the corrosion in the passage will spread quickly, and the cooling performance will be consequently lowered. This can shorten the service life of the engine.
	In cold weather, use a antifreeze. For further details, see Sec. 8-3 #7).	⚠ Caution: Antifreeze prevents the fresh water passage from being cracked by freezing. Determine the mixing ratio of fresh water and antifreeze according to the lowest ambient temperature. The mixing ratio of more than the specified value may cause engine overheating.
	Change the fresh water every 1000 service hours.	Contamination of fresh water lowers the cooling performance, abnormally raises the engine temperature, and causes engine trouble such as seizure.
	Before starting the engine, check the fresh water level in the subtank. In addition, check the water level in the fresh water tank at least once a week. For further details, see Sec. 5-3 #2)	If the level of fresh water goes down, the temperature of the fresh water abnormally rises and causes seizure of the parts.

No.	Precautions	Troubles Due to Failure to Observe
4	Do not loosen the pressure cap during operation, or immediately after the engine has been stopped. Wait until the temperature falls below 60 °C.	 Warning: If the pressure cap is loosened while the fresh water is still hot, hot water may gush out and cause injury to the operator (burns). Should the pressure cap be loosened while the water is still hot, cover the cap with waste cloth, etc.
	If the temperature of the cooling water rises above 85 °C saling may occur in the fresh water and sea water passage.	Higher temperature of the cooling water, in most cases, causes decrease in the cooling performance. If the engine continues to run with decreased cooling performance, the service life of the engine will be shortened or seizure of parts may occur. In such a case, consult the nearest YANMAR dealer.
5	Do not operate the engine while the seawater pump is not drawing up seawater.	 Caution: If the engine runs while the pump is not drawing up seawater, the seawater pump impeller will seize after approximately 30 seconds and be permanently damaged. If the operation is continued under such conditions, the temperature of the fresh water will rise excessively, and serious problem will occur, such as seizure of pistons or crank shaft. An alarm is employed to detect the abnormally high temperature of fresh water.
	When turning the engine manually, be sure to turn it in the normal engine rotating direction. For further details, see Sec. 5-9.	The seawater pump impeller will fracture and be damaged permanently. If the engine is turned in the wrong direction, the sea water pump impeller may be damaged permanently.
	In cold weather, be sure to completely drain the water from the seawater passage after engine shutdown. For further details, see Sec. 6-4 #4).	 Caution: If seawater remains in the passage and freezes, it will cause the cooler and seawater pump to be permanently damaged.

No.	Precautions	Troubles Due to Failure to Observe
6	When removing the fuel injection valve, thoroughly remove carbon deposits on the perforated nozzle seat surface, and replace the seat packing with a new one.	Carbon deposits on the nozzle seat surface may cause gas leakage or corrosion. Consequently, gas leakage or corrosion may make it difficult to pull out the fuel injection valve or requires replacement of the nozzle sleeve. Be sure to ask the authorized YANMAR dealer to perform overhaul and assembly of the fuel injection valve.
	Do not forget to place the dust seal back onto the fuel injection valve. If the dust seal has aged or become damaged, replace it with a new one.	⚠ Caution: Torque the fuel injection valve securing nut to 0.7~0.9 kg-m.
7	When using optional trolling valve, run the engine at a speed of 1400 rpm or lower, and do not continue trawling more than 2 hours. When not trawling, set the trolling lever to the H position (high speed), and be sure to lock it.	Failure to do this will cause the clutch friction plate to seize up.
8	Be sure to warm up the engine. For further details, see Sec. 6-2.	To allow lube oil to be distributed to all necessary parts, warm up the engine for approximately 5 minutes at 700 to 800 rpm after starting the engine. Insufficient warming up may cause abnormal wear or seizure of the moving parts.
9	Check the alternator drive belt for tension, and adjust it whenever necessary. For details of the adjustment, see Sec. 8-7 #4).	⚠ Caution: If the tension is not properly adjusted, power is not transmitted appropriately and the drive belt may be damaged or broken. Moreover, improper belt tension may cause insufficient electric charging, with the result that the engine cannot be started.
10	Do not continuously use the starter motor for more than 15 seconds.	⚠ Caution: Prolonged operation of the starter motor (continuously for more than 15 seconds) may cause seizure of the starter motor.

No.	Precautions	Troubles Due to Failure to Observe
11	Be sure to properly ventilate the engine room.	 Warning: Install a ventilator or provide vent holes. Insufficient air intake will increase the temperature in the engine room, resulting in reduction of engine output or deterioration of engine performance. (The capacity of the ventilator should be 40 m³/min. or greater.)
12	<p style="border: 1px solid black; padding: 5px; text-align: center;">Important : Extra care should be taken when handling the turbocharger and air cooler.</p> <p>(1)Check that the joint section between the turbocharger and the manifold is not damaged, or air does not leak from the joint section.</p> <p>(2)Do not suddenly reduce the load or stop the engine after full-speed navigation.</p> <p>(3)If the air intake pressure drops, clean the pre-filter and blower.</p>	<p>Damage or leakage may cause reduction in output.</p> <p>The turbocharger impeller may be damaged.</p> <p>If the engine is operated with reduced air intake pressure, the combustion performance will be lowered. For further details, refer to Section "Handling the Turbocharger."</p>
13	When you restart the engine after long suspension of operation, sufficiently lubricate the engine. To do this, pull the engine stop knob, and rotate the engine using the starting motor for 5 to 10 seconds.	Do not start the engine without lubricating the engine. Otherwise, the cylinder liner, metal, or movable parts in the valve system may seize up, and the service life of the engine may be shortened.

4. FUEL AND LUBE OIL


4-1 Selection and Handling of Fuel

1) Selection of fuel

It is recommended that a diesel #2 with cetane number 45 or more be used, whichever is best-suited for the required engine performance.

2) Handling of fuel

- (1) Fuel containing water, dirt, sludge or other impurities may cause engine trouble.
- (2) Place the drum of fuel oil upright, and allow it to stand until all impurities have settled. After this, place a suction tube halfway down the drum, and draw up fuel oil at that level.



▲ Caution:

We are not liable for damages to the engine caused by use of improper fuel oil.

4-2 Selection of Lube Oil

1) Selection of lube oil

Selection of the proper lube oil is essential to the optimum operation of the diesel engine. Using an improper lube oil or failure to follow regular oil changes will result in the following problems:

1. Piston ring sticking
2. Seizure or premature wear of pistons and cylinder liners
3. Premature wear of bearings and other moving parts
4. Shorter engine life

▲ Caution:

- If you have any questions regarding the selection of the proper lube oil, consult your nearest YANMAR dealer.
- If a lube oil other than those recommended above is used, the service life of the engine may be substantially reduced.
- If lube oils of different brands are blended the quality of the lube oil may deteriorate. To prevent this, do not use a mixed lube oil.
- We are not liable for damages to the engine caused by the use of improper lube oil.

5. INITIAL OPERATION OF NEW ENGINE

When operating a new engine for the first time, follow the procedures described below.

5-1 Fuel Supply

Check again that the inside of the fuel tank and the pipes in the fuel system have been thoroughly cleaned.

After doing this, supply fuel to the tank. Follow these steps after the 1st operation:

1) Draining Impurities

Even if high quality fuel is fed to the tank, some dirt and water may have been mixed in the fuel.

To prevent these impurities from entering various components, it is necessary to eliminate them. This step is called drainage.


2) Drainage of fuel tank

Be sure to provide a water separator or precipitation tank having a drain valve to the fuel tank. Periodically open the drain valve to eliminate impurities.

3) Draining fuel oil filter

Loosen the drain plug shown in the photo to drain the filter. If reddish and rusty colored water comes out, there may be a considerable accumulation of water and dirt. In this case, disassemble and clean the fuel oil filter.


For further details, see Sec. 8-1.



5-2 Lube Oil Supply


1) Lube oil supply to oil pan

Remove the oil port cap from the side plate, and supply lube oil as shown in the photo below.



2) Checking the oil level

Completely insert the dipstick and check the oil level. If the oil level is lowered, supply lube oil up to the full below the ADD mark marker on the dipstick.



Operating side Non-operating side



Do not overfill oilpan.

Amount of oil at the upper limit makers on the dipstick

20 l

3) Lube oil supply to reduction and reversing gear supply by Yanmar.

Supply lube oil from the oil port shown in the photo below. The procedures for supplying lube oil and checking the oil level in the reduction and reversing gear box are similar to that for the engine.



Amount of oil at the upper limit marker on the dipstick

KMH6A 4.0 l

Consult appropriate manual if non-Yanmar gear

5-3 Cooling Water Supply to Fresh Water Tank

Use clean soft water (tap water) for the fresh water tank.

1) Tightening the fresh water drain valve

Before supplying fresh water to the tank, be sure to tighten the 2 water drain valves shown in the photo below.




2) Water supply

Check that the hose between the subtank and fresh water tank is securely tightened. The subtank must be in a position where the top of the subtank is equal to that of the fresh water tank, or lower by approximately 5 cm, than the fresh water tank.

Remove the pressure cap of the fresh water tank, and supply fresh water to the fresh water tank until water flows out of the port. Supply fresh water also to the subtank to the lower limit level.

For the amount of fresh water, see Sec. 2.




3) Tighten the pressure cap securely.

If the pressure cap is not tightened sufficiently, fresh water may spill out during operation. In addition, hot water may gush out causing injury to the operator (burns).

5-4 Tightening Drain Cock of Seawater System

Before you start the engine, be sure to tighten 3 drain valves shown in the photos below:





5-5 Bleeding Air from Fuel System

For the air removal procedures, refer to Sec. 9-1.

5-6 Lubricating Each Section

Lubricate the ball joints of the throttle lever, clutch change lever, and remote control cable.



5-7 External Inspection

Check that tools or other things are not placed on the moving parts or on the engine, and ensure that the engine room is neat.

5-8

Checking Operation of Remote Control Unit

- (1) While operating the throttle lever from lower speed position to the high speed position, check that there is no difference in operation between the wheel house and engine side. If a difference is detected, adjust the throttle lever.
- (2) While operating the clutch lever from the AHEAD position, NEUTRAL position, to ASTERN position, check that there is no difference in operation between the wheel house and clutch side. If a difference is detected, adjust the clutch lever.

5-9

Starting Engine for the First Time

It is suggested that the stop lever, on the fuel injection pump, replace in the stop position, the starter should then be engaged for 3.5 second. During this procedure, listen for any abnormal sound.


5-10

Checking Operation of Gauges (Standard Tanmar Panel)

When you set the starter switch to the ON position, the condition of panel is as follows:

- (1) The warning light for lube oil pressure is ON.
- (2) The warning light for charging is ON.
- (3) The cooling water temperature light is off.
- (4) The tachometer indicates "0".
- (5) The hour meter operating.
- (6) The alarm sound continuously.

Turn on the elimination switch, and check the elimination lamp of the tachometer is ON.




Applicable voltage	DC12V
Fitting angle	Glass surface of instrument panel : $30^\circ \pm 15$ against
Tachometer	0 to 4, 100 rpm., electromagnetic pickup sensor
Warning indication	Warning lamp, buzzer, and 1-segment indication, cooling water level down, cooling water temp. up, oil pressure down, clutch oil pressure down

5-11 Checking Alarm Devices (Standard Tanmar Panel)

When the engine is started, the alarm lights for lube oil pressure and charging should go out and buzzer should become quite.

- Charging
- Lube oil pressure
- Cooling water temperature
- Lube oil filter
- Cooling water level




5-12 Re-checking Starting Engine for the First Time

After a new engine has been run for the first time, the level of the oil in the oil pan may slightly go down because the lube oil has been thoroughly distributed to the lube oil cooler and lube oil filter. In this case, stop the engine and leave it for a while (approx. 5 minutes), and then check again for the following items:

- 1) Check the oil level in the oil pan using the dipstick.
- 2) Check the oil level in the marine gear box using the dipstick (YANMAR gear). The level may be lower than full marker F; however, this is not abnormal.

Supply oil if the oil level is below lower limit position L.



The amount of oil between upper limit position F and lower limit position L is approximately 0.3 liters.

The oil level is normal when it is between upper limit position F and lower limit position L.

- 3) Remove the pressure cap from the fresh water tank, and check the water level. The level may be lower due to air entry from the fresh water passage. In this case, supply fresh water until water flows out of the water port.


6. OPERATION

Before starting the engine, check around the engine to see that there is nothing that may prevent safe operation.

6-1 Starting

Follow these steps to start the engine:

- 1) Set the remote control clutch lever to neutral position.
- 2) Set the remote control throttle lever to the normal speed position (midpoint between high speed position and slow speed position).



Turn the key of the starter switch to the START position to start the engine. As soon as the engine is started, release the key; the key automatically returns to the ON position.

⚠ Important: Do not turn off the battery switch even after starting the engine.

With the start switch at the ON position, the gauges and alarms on the Tanmar instrument panel are activated.


⚠ Important:

- (1) To protect the starter, do not continue running the starting motor for more than 15 seconds. If you fail to start the engine, wait about 15 seconds and then try again.
- (2) When restarting the engine, make sure that the engine has stopped and turn the starter switch key to the START position. If the starter switch is turned while the engine is still running, the starter motor and/or flywheel gears may be damaged.
- (3) To facilitate the start-up of the engine in cold weather:
 - Turn off the boost compensator. Pull the low temp. starter knob all the way out. When the engine has started, push low temperature knob all the way in. The boost compensator once turned off will automatically be activated after starting the engine.

⚠ Caution: Use the low temp. starter knob only when start-up of the engine is not easy. During normal operation, push and keep the knob as it is.

⚠ Warning:

Disconnect the terminals from the battery before repairing or inspecting electrical parts.



6-2

Cautions Required Immediately After Starting

While keeping the clutch lever at the neutral position, follow the procedures described below.

- 1) Immediately after starting the engine, run the engine for 5 to 10 minutes at approximately 700 rpm.
- 2) Check that water is flowing out of the cooling water outlet pipe.
- 3) Check that the CHARGE lamp goes out.

Note: After launching and running the engine for the first time, continue to warm-up the engine for 10 to 15 minutes.

6-3

Cautions Required During Operation

⚠ Caution:

Be sure to check the following items once or twice daily during engine operation.

1) Cooling water (seawater)

Check that water is flowing out of the cooling water outlet pipe.

If water is flowing out intermittently or the volume of the flowing water is small, there may be the following problems:

- (1) Air has been taken in to the cooling water system.
 - (2) The impeller or other parts of the cooling water pump are malfunctioning.
 - (3) The cooling water pipe or kingston valve is clogged with foreign solids.
- If you cannot identify the cause of the problem, return to nearest port at low speed and consult the nearest YANMAR dealer.

2) Cooling water (fresh water)

The temperature of the fresh water must not rise above 90 °C (75 °C to 85 °C for a new engine) during operation. Temperatures higher than 90 °C indicate that a problem has occurred in the cooling water system.

The cause of the problem may be as follows:

- (1) The volume of fresh water rapidly reduces due to leakage from the cooling system. If the temperature of the fresh water rises abnormally, the alarm will sound.
- (2) The flow rate of fresh water is insufficient due to failure in the fresh water pump or clogging of the fresh water passage.
- (3) The seawater pump is malfunctioning, or the seawater passage is clogged.
- (4) Fresh water is not cooled sufficiently due to a contaminated cooler.

If you cannot identify the cause of the problem, return to port at low speed and consult the nearest YANMAR dealer.

⚠ Cautions:

Temperature of fresh water

When the temperature of fresh water rises after start-up, heated water flows into the subtank from the fresh water tank and the volume of fresh water in the subtank increase. Note that this is normal.

After the water temperature drops after stopping the engine, the water automatically returns to the fresh water tank.

3) Exhaust color

Continuous exhaust smoke is a sign of improper engine operation. As a result, the service life of suction valves, exhaust valves, piston rings, cylinder liners, and, especially, the fuel injection valves are shortened. Do not operate the engine if continuous black smoke is emitted.

▲ Caution:

4) Water and oil leakage, and other operating conditions

From time to time, check that there is no water leakage, oil leakage, head gasket leakage, loose bolts, abnormal noise, abnormal heat, and abnormal vibration. If any of such abnormalities are found, consult the nearest YANMAR dealer.

▲ Caution:

5) Operation of clutch lever

When operating the clutch lever, lower engine speed down below 1000 rpm.

Engaging or disengaging the clutch suddenly during high speed operation or operating the clutch at a half-engaged position may result in clutch seizure and shorten the service life of the clutch.

▲ Caution:

6) Abnormal noise during operation

If unusual noise is generated during operation, or if the alarm buzzer sounds during operation, check first to see which alarm lamp is lit, and turn off the buzzer switch. Then immediately stop the engine. Note that sudden deceleration may activate the clutch oil pressure alarm. However, this is not abnormal.

Investigate the possible causes of the trouble. If the cooling system and lube oil system are free of problems, return to the nearest port at low speed and consult the nearest YANMAR dealer.

7) Prolonged operation at low speed

When operating the engine at low speed for a prolonged period of time, "race" the engine every 3 to 4 hours or so.

▲ Important:


"Racing" is required to discharge the deposits that have accumulated on the cylinders during low speed operation and to prevent the contamination of the cylinders. For "racing," disengage the clutch and run the engine at 1800 rpm for about 1 minute.

6-4

Stopping

1) Before stopping the engine, "race" the engine.

- (1) Set the clutch lever to the N position (neutral), and idle the engine for about 5 minutes.
- (2) "Race" the engine for about 5 seconds at approximately 1,800 rpm.
- (3) Reduce speed to the idle speed and stop the engine.



▲ Caution: If the engine is stopped in a heated condition, the temperatures of the fresh water and the engine parts may rise rapidly, possibly causing troubles. (See 6-4,#1)

- 2) After stopping the engine, set the starter switch to the OFF position.

3) Draining of cooling water:



In cold weather, cooling water (seawater) may freeze. After shutting down the engine, be sure to drain the water from the system. (Use antifreeze for fresh water.)

When the engine is not used for a prolonged period of time, drain all the water from the system.

If seawater is left in the system, it may freeze and break the cooler or the seawater pump.

Drain cooling water (seawater) by following the steps:

- (1) Loosen the water drain valve of the clutch lube oil cooler. (Yanmar marine gear)
- (2) Loosen the bolts on the seawater pump cover.



7. HANDLING THE MARINE GEAR

7-1 Handling Precautions


- 1) The durability of the marine gear largely depends on how it is handled. When shifting the clutch lever to ASTERN from AHEAD or vice versa, be sure to slow down the throttle lever to reduce the speed (lower than 1000 rpm), set the clutch lever once to the neutral position, and then set it to the ASTERN or AHEAD position.
- 2) Do not attempt to operate the throttle lever before completing the operation of the clutch lever. Shifting the clutch lever suddenly to AHEAD or ASTERN with the engine running at high speed may cause the clutch to malfunction. Never perform such an operation.

7-2 Handling the Emergency Bolts


- 1) Should trouble occur in the marine gear lube oil system during operation, stop the engine and remove the emergency bolt plug from the clutch case. Then slightly and uniformly tighten four emergency bolts on the clutch rotation section by turning them clockwise. After that, firmly tighten the bolts again. To view the emergency bolts again, the engine must be rotated slowly until the emergency bolt are visible through the emergency bolt plug hole.
- 2) Now the clutch is connected to the ahead side. You can temporarily run the engine at a low speed (2000 rpm or less).

Warning:

High speed operation may cause seizure of the clutch disc or metal.



Emergency bolt plug
Emergency bolt



Warning:

- (1) To tighten the emergency bolts, turn the engine until the head of the bolt lines up with the hole, and tighten the four bolts evenly.
- (2) When using the emergency bolts, the clutch is directly connected to the forward and cannot be used in the neutral or astern position. Thus, special care must be taken when starting the engine and entering port.
- (3) After returning to port using the emergency bolts, ask the nearest YANMAR dealer to service the engine as soon as possible.
- (4) Turn off the battery main switch before inspecting the clutch.

- 1) Checking the marine gear lube oil
Remove the dipstick before starting the engine, and check that the oil level is between the upper limit and lower limit. Supply lube oil if required.
- 2) Cleaning the marine gear lube oil cooler fouled or clogged by seawater
- 3) Changing the marine gear lube oil
- 4) **Checking the bearings, friction plate thickness, rubber block, and seal**
To check the bearings, friction plate, rubber block, and seal, the reduction and reversing gear needs to be disassembled. Ask the nearest dealer to undertake the servicing.
- 5) Cleaning the lube oil filter
- 6) Checking connection of the remote control cable

The items 1) through 6) above are prerequisite to correct operation. For further details, see Sec. 8.

8. PERIODICAL CHECKS AND SERVICE

To keep the engine in best condition, periodical checks are essential. The parts that require periodical maintenance are located on top of the engine.

Maintenance

1. Sub tank: Check and replenish cooling water
2. Fuel oil filter: Replace filter every 250 hours.
3. Lube oil filter: Replace filter every 250 service hours. (1st replacement: At 50 service hours)
4. Turbocharger compressor: Clean compressor every 250 service hours.
5. Lube oil dipstick and oil drain pipe: Before start-up check oil level using dipstick.

Draining method: Remove dipstick, and drain waste oil by sucking it up the oil drain pipe. (Dipstick tube.)

6. Lube oil port

Applicable lube oil: Class CD, 15W-40 for engine, and class CD, #30 for clutch.

Lube oil replacement: Every 250 service hours.

Replacement amount: 18 liters

Maintenance List

● : Consult nearest dealer.

○ : Check ◉ : Replace

Item	Description	Schedule					Page
		Daily	Every 50 service hrs.	Every 250 service hrs.	Every 500 service hrs.	Every 1000 service hrs.	
Fuel	Check of fuel level	○					24
	Draining of tank		○ (Before oil supply)				25
	Draining of filter and water separator		○				25
	Replacement of filter element			◉			26
Engine lube oil and Marine gear lube oil	Check oil level in oil pan, add if necessary	○					26
	Replacement of filter element (including bypass filter)		○ (1st time)	◉			26
	Cleaning of lube oil cooler					●	27
	Change of lube oil	Engine side	○ (1st time)	○			27
							—
Cooling water (seawater side)	Check of cooling water discharge	○					28
	Check and replacement of impeller				○	◉	28
	Cleaning of seawater system (including fresh water and lube oil cooler)				●		29
	Check and supply of fresh water level	○					29
Fuel injection pump and fuel injection valve	Replacement of fresh water				●		30
	Cleaning of fresh water system (including heat exchanger tank)				●		30
	Adjustment of injection timing				●	●	25
	Overhaul and check of fuel feed pump				●	●	25
	Adjustment of injection pressure and atomizing condition		● (1st time)		●		25
	Replacement of fuel injection valve				●	●	25

Item	Description	Schedule							Page
		Daily	Every 50 service hrs ● (1st time)	Every 250 service hrs ○ (1st time)	Every 500 service hrs	Every 1000 service hrs	Every 2500 service hrs ●	Every 6000 service hrs	
Cylinder head	Adjustment of clearance intake and exhaust valve		●				●		—
	Check and adjustment of remote control cable		○	○					32
Electrical parts	Check of alarm derices	○							32
	Check of battery electrolyte volume			○					32
	Adjustment of alternator (generator) drive belt tension				○				33
	Replacement of battery of liquid crystal display clock						○		33
Turbo-charger	Cleaning of blower			○					37
Intercooler	Flushing		○						—
Marine gear (Yanmar marine gear)	Check and cleaning of lube oil cooler						●		31
	Check and cleaning of lube oil inlet filter net		○ (1st time)		○	●			31
	Check of bearings, friction plate, and seal						●		31
	Check of lube oil level	○							31
	Change of lube oil		○ (1st time)		○	○			27

Adjustment table

Item	Standard value		
	6LY-STE	6LYM-STE	
Clearance of intake and exhaust valve (in cold condition)	Intake : 0.1 ± 0.05 mm ; Exhaust : 0.5 ± 0.05 mm		
Intake valve	Open Crank angle : Before T.D.C.	59° ± 5	
	Close Crank angle : After B.D.C.	63° ± 5	
Exhaust valve	Open Crank angle : Before B.D.C.	58° ± 5	
	Close Crank angle : After T.D.C.	46° ± 5	
Fuel injection start	Crank angle : Before T.D.C.	13° ± 1	
Pressure	Fuel injection start pressure	260 ± 10 kg/cm ²	
	Engine lube oil pressure (at rated r.p.m)	5 ± 0.5 kg/cm ²	
Temperature	Cooling water temperature at engine outlet	45°C or less (at inlet: 30°C) ; Seawater temperature: +10°C	
	Lube oil temperature at cooler inlet	95°C or less	
Engine fresh water capacity		24 l	
Amount of lube oil		F : 20 l L : 8 l	
Clutch oil pressure	Original pressure in neutral status	2~3 kg/cm ² (500rpm)	
	Hydraulic oil pressure in engaged status	24 ± 0.5 kg/cm ² (3300rpm)	
	Lube oil pressure	2.0 ± 0.5 kg/cm ² (3300rpm)	
		Marine gear box	

Torque Requirements for Major Parts

Engine	Torque requirements for major parts	Cylinder head bolt	21±1kg-m		
		Main bearing retaining bolt	26±1kg-m		
		Connecting rod bolt	14±0.5kg-m		
		Flywheel mounting bolt	30±1kg-m		
		Nozzle fastening nut	0.7~0.9kg-m		
		Valve arm support shaft tightening nut	1.7±0.2kg-m		
		Fuel oil pump drive gear tightening nut	13±1kg-m		
Clutch	Part		Screw diameter	Tightening torque (kg-m)	
	Pump tightening bolt		M8	2.1±0.2	
	Emergency bolt pulg		M10	4.0±0.2	
	Output shaft joint bolt		M16	23±1.5	
Output shaft snap nut		M40	70±2.5		

Torque Requirements for Standard Bolts

Screw diameter × pitch (mm)	M6×1	M8×1.5	M10×1.5	M10×1.75	M14×1.5	M16×1.5
Torque (kg-m)	1.1±0.1	2.6±0.2	5.0±0.5	9.0±0.5	14±1	23±1.5

Notes:

Torque requirements for bolts other than the major bolts should conform to the table above.

The bolts to be tightened to the torques specified above should be those made of S45C material which are identified by having "7" marked on the bolt head.

(When the material of the tightening part is aluminum, tighten it to 80% of the torque listed above.)

8-1 Fuel Oil System


For the diagram of the fuel oil system, refer to Sec 10.

1) Checking the fuel oil level in the fuel tank and replenishing

Level check	Daily
-------------	-------

Replenish fuel oil whenever necessary. For details of the procedures, refer to Sec. 4-1.

[Reference] The fuel piping system is generally configured as shown in the figure below.



2) Draining the fuel oil tank

Open the drain valve of the tank, and discharge impurities accumulated on the bottom of the tank.

Schedule	Daily (or before fuel oil replenishment)
----------	---

3) Draining the fuel oil filter and changing the filter element

(1) Draining the filter attached to the engine

Remove the drain plug, and discharge water and dirt accumulated in the filter.

Schedule	Every 50 service hrs (or weekly)
----------	-------------------------------------

(2) Changing the filter element


1) Remove the element using the element removal tool.

2) Replace the element with a new one, and reassemble the filter.

Before you install the packing, clean the packing installation surface. Install the packing while checking that there are no foreign materials on the packing installation surface.

3) Operate the engine, and check that fuel oil is not leaking.

Schedule	Every 250 service hrs (or 2 or 3 months)
----------	---





4) Checking and adjusting the fuel injection timing

(1) Remove the high-pressure fuel oil pipe from the fuel injection pump.

(2) While manually turning the flywheel slowly, check that the timing of the fuel flowing out of the discharge valve holder of the cylinder injection pump conforms to the specified timing by visually inspecting the flywheel and indicator.

(3) Check the fuel injection timing of all the cylinders by following the step (2) above. (If the observed timing does not confirm to the specified timing, consult the nearest YANMAR dealer.)


Inspection schedule	Every 2500 service hrs (or annually)
Fuel injection timing	6LY(M)-STE 13°±1



5) Drainage of oil-water separator

Remove the drain plug, and discharge water and dirt accumulated in the oil-water separator.

Schedule	Every 50 service hrs (or weekly)
----------	-------------------------------------



8-2 Lube Oil System

1) Checking the lube oil level in oil pan

For the diagram of the lube oil system, refer to Sec. 10.


Remove the dipstick before starting the engine, and check that the lube oil level is between the upper limit and lower limit. Replenish the lube oil whenever necessary.

For details of the lube oil check, refer to Sec. 5-2.

Inspection schedule	Daily (before start-up)
---------------------	-------------------------

2) Changing the lube oil filter

Remove the filter, and replace the filter element with a new one.



Schedule	1st replacement	At 50 service hrs (or 1 week)
	2nd and subsequent replacements	Every 250 service hrs (or monthly)

- Procedure for changing the filter element

- (1) Remove the filter element using the oil filter wrench.
 - (2) Replace the filter with a new one. At the same time, clean the seating surface of the packing to prevent improper sealing caused by foreign material. Apply small amount of lube oil filter sealing ring.
 - (3) Check that there is no oil leakage during operation.

3) Changing the lube oil

Change the lube oil while the engine is still warm after shutdown.

In this condition, the oil flows smoothly and can be drained completely.


Schedule	1st change	At 50 service hrs
	2nd and subsequent changes	Every 250 service hrs

Change the lube oil of the reduction and reversing gear by following the procedure described above.

4) Cleaning the lube oil cooler

Consult the nearest dealer.

Schedule	Every 2500 service hrs
----------	------------------------

8-3**Cooling Water System (Seawater and Fresh Water)****Seawater Pump****1) Checking the seawater discharge conditions**

During operation, occasionally check that the water is properly flowing out of the seawater outlet pipe. If the seawater comes out intermittently or the rate of the water flow is lower during high-speed operation, immediately stop the engine and identify the cause of the trouble.

(For further details, refer to Sec. 6-3-1).


Inspection schedule	Daily (during operation)
---------------------	--------------------------

2) Checking and changing the seawater impeller and casing

(1) Remove the cooler of the seawater pump, and pull out the impeller. Check to see if there is damage on the impeller, wear plate, cover, and mechanical seal.


Inspection schedule	Every 500 service hrs
---------------------	-----------------------

- (2) If the wear plate or cover is worn out, turn it over for reuse.
 - (3) When assembling the pump, apply grease to the impeller shaft and impeller, both end surfaces of the impeller, and the tips of the blades.
 - (4) To mount the impeller, set the impeller blades as shown in the photo below.



Inspection schedule	Every 1000 service hrs
Impeller replacement	Every 2500 service hrs

Fresh water pump



Caution:

3) Cleaning the seawater system (including fresh water and lube oil cooler)

When the seawater system has been used for a prolonged period of time, the cooler will be contaminated by dirt, and the cooling performance drops. As a result, the temperature of the fresh water rises abnormally (higher than 85°C). To avoid such a problem, cleaning is required. Ask the dealer to clean and service the seawater system.

Schedule Every 1000 service hrs

4) Checking the fresh water level

(1) Checking the fresh water level in the heat exchanger tank

Remove the pressure cap from the heat exchanger tank, and check the water level in the tank. Normally, the tank should be filled to its maximum capacity. If the water level is low, add water to fill up the tank.

(2) Checking the fresh water level in subtank

Normally, the fresh water tank should be filled to its maximum capacity, and the water level in the subtank to at least the lower limit level mark. If the water level in the subtank is below the lower limit level mark, add water so that the water level reaches the upper limit level mark.

▲ Important:


1. If water is left in the subtank even though the water level in the fresh water tank is lowered, the rubber rubber joint between the fresh water tank and subtank may be loosened or the pressure cap may be damaged. In this case, consult the nearest YANMAR dealer.
2. Checking the volume of the fresh water in the heat exchanger tank only by the water level in the subtank is unreliable. Check the water levels in both the heat exchanger tank and the subtank.

Inspection schedule	Daily
---------------------	-------

5) Checking of water leakage from fresh water pump

Water leakage from the fresh water pump may cause serious problems such as engine seizure.

Check that water is not leaking from the drain hole of the fresh water pump. If water has leaked from the drain hole, consult the nearest YANMAR dealer.



Inspection schedule	Daily
---------------------	-------

6) Cleaning the heat exchanger tank and thermostatic valve

When the heat exchanger tank has been used for a prolonged period of time, the cooler may become contaminated with dirt. As a result, the temperature of the fresh water rises abnormally (higher than 85°C), and the cooling performance drops. Be sure to clean the heat exchanger tank at the required time intervals.

At the same time, also clean the thermostatic valve.

Consult your nearest YANMAR dealer for maintenance service.

Schedule	Every 1000 service hrs
----------	------------------------

7) Changing the fresh water

Schedule	Every 1000 service hrs
----------	------------------------

(1) Application of antirust agent

Fresh water forms deposits of scales and rust on the fresh water passage, which lowers the cooling performance. Add antirust to the fresh water.

(2) Application of antifreeze

In cold areas where cooling water may freeze, be sure to add antifreeze to the fresh water. Do not add an excessive volume of anti-freeze.

8-4 Lubrication of External Parts

Lubrication of external parts

Lubricate the throttle lever of the fuel oil pump, clutch lever, and ball joint of the remote control cable.

8-5 Checking the Marine Gear (Only for 6LY-STE)

1) Checking the lube oil level and replenishing the lube oil

Before start-up, remove the dipstick and check that the oil level is between the upper and lower limit marks. If the oil level is below the lower limit mark, replenish the lube oil.

For the check and replenishment methods, refer to Sec. 5-2,#3.

Inspection schedule	Daily (before start-up)
---------------------	-------------------------

2) Changing the lube oil

Change the lube oil while the engine is still warm after shutdown.

In this condition, the oil flows smoothly and can be drained completely.

To remove the waste oil, pump the oil out by connecting the suction hose to the dipstick guide, or drain the oil by loosening the drain plug on the clutch case.


Amount of the lube oil at the upper limit marker on the dipstick

KMH6A 4.0 l

Schedule	1st change : At 50 service hrs 2nd change : At 250 service hrs 3rd and subsequent change : Every 1000 service hrs
----------	---

3) Checking and cleaning the lube oil filter

Remove the filter from the clutch case, and wash it with solvent.



Inspection schedule	1st inspection : At 50 service hrs after overhauling 2nd inspection : At 250 service hrs after overhauling 3rd and subsequent inspections : Every 1000 service hrs
---------------------	--

4) Checking and cleaning the oil cooler

Consult the nearest dealer.

Inspection schedule	Every 2500 service hrs
---------------------	------------------------

5) Checking and replacing the bearings, friction plate, rubber block, and seal

Consult the nearest dealer.


Schedule	Every 6000 service hrs
----------	------------------------

8-6

Adjusting the Remote Control Cable


1) Adjusting the throttle lever (Option)

Shift the throttle lever from the slow speed position to the high speed position, and check that the corresponding lever position is indicated at other stations. If there is any difference in indication, adjust the throttle lever by using the cable adjustment bolt.



2) Adjusting the clutch lever

Operate the clutch lever to the AHEAD, NEUTRAL and ASTERN positions, and check that the lever for the reduction and reversing gear moves firmly to the intended position. If the lever does not operate properly, adjust the lever by using the cable adjustment nut.



8-7

Checking the Electrical Parts

⚠ Caution:

Disconnect the terminals from the battery before inspecting electrical parts.

1) Checking the alarm lamps

2) Checking the alarm devices

For details of the procedures for checking the alarm devices, refer to Sec. 5-10 and 5-11. If any abnormality is found, consult the nearest YANMAR dealer.

Inspection schedule	Daily
---------------------	-------

3) Checking the battery electrolyte

The level of electrolyte gradually decreases through repeated charging and discharging. (In particular, the amount of decrease is larger in hot weather than cold weather.) Before starting up, check the level of the battery electrolyte. If the level is lower, add commercially-available distilled water.

Inspection schedule	Monthly
---------------------	---------

 **Warning:** Handle the battery with utmost care. If you accidentally get electrolyte on your skin, or clothing, wash immediately by water.


4) Checking and adjusting the alternator (generator) drive belt tension

The tension of the V-belt that drives the alternator (generator) should be correctly adjusted. Excessive tension may accelerate wear of the belt. In contrast, a loose belt may cause pulley slippage, with the result that power is not generated.

- (1) To exert tension on the V-belt, loosen the fastening bolt shown in the photo below and pry the alternator away from the engine. To loosen the belt, loosen the fastening bolt and push the alternator toward the engine block.


(2) Do not handle the belt with greasy hands or allow any oil to come in contact with the belt. Oil on the belt will cause the belt to slip.

Belt tension	Approx. 8~10 mm or less deflection
Inspection schedule	Every 500 service hrs



8-8


Handling of Electrical Bilge Pump (Standard Yanmar Model)



1) Features

- (1) By pushing the switch of controller once the pump starts draining and will automatically stop at the level where the lower water-level sensor detects.
- (2) In case you want to drain further, the pump again drains continuously by keeping the switch pushed. It is automatically back to "switch off" when the switch is released.
- (3) In case of oil, it does not stop automatically.

It can be used by keeping the switch pushed.




Installation of motor assembly

- Select a location of installation where the motor is at a level higher than the bilge water and will not be affected by rain and water.
- Location should be selected taking account of the distance from battery and controller.
- Install the motor at a position of 50 to 70 cm above the bilge with the motor body inclined by ward, as shown in Fig.

Installation of controller

- Install the controller in a location where and applied with no rain.
 - Connect the controller terminals to battery (pay attention to battery Voltage).
- In case additional wiring is necessary due to remote from battery, use AV3 wire or one of more than 3 square millimeter of which the length shall be not more than 3 meters.




Installation of strainer

- Select a location of installation where of bilge water the greatest amount is anticipated when the boat is not running.
 - The strainer should desirably be as near the motor as possible.
- Select a place where the strainer is sufficiently connectable to the inlet hose A (transparent, 1.5 m long) from the bilge pump.
- After checking by a test run, fix the strainer to the bilge with screws.
 - In case of deluxe type, connect a hose to the pipe on the strainer as shown in Fig. and then this automatically starts draining when the water comes up to the height of the hose, and again stops draining automatically when the water comes down.
 - The strainer should be always kept clean.

Installation of Delivery nozzle (outlet)

- Select a location where the nozzle is kept above the water-line and can be connected with the hose B (black) as not stretched, but situated as near the pump as possible, then make a hole of $\phi 21$. Fix the delivery nozzle in the hole and insert the end of the hose (black).



Connection of hoses

- Insert the hose A (transparent, 1.5 m long) from the strainer to the inlet of the pump. (follow the direction of arrow)
 - Insert the hose B (black, 1.8 m long) from the delivery nozzle to the outlet of the pump. (follow the direction of arrow)
- These hoses should be as short as possible and should not be extremely bent.

Test run

- Put water in the bilge and connect the pipes and wires as shown at page 1. Check the wiring if any misconnection. Finally connect to the battery without misconnecting (+) and (-).

- In case of standard type, press the switch for a moment and make sure that the pump starts suction and delivery of the bilge water.
- In case of deluxe type, push the switch to fully-automatic and make sure that the pump starts suction after approximately 3 seconds when the water is over is the level of the upper water-level sensor, and stops automatically when the water is below the level of the lower water-level sensor.
- When the inside of the pump is dry, it is hard to suck water by itself. If no suction comes out within 10 seconds, take the strainer out of the water, stop the pump and again make sure that after priming, the pump starts suction and delivery.

Installation of strainer

- After the test run is confirmed, fix the strainer to the bilge with screws. (Be careful that the screws are not gone through the bilge.)

8-9 Checking the Turbocharger

1) Cleaning the turbocharger inlet

(1) Suggested on cleaning schedule

Cleaning schedule	When the boost pressure drops approx. 10% compared with that of the test run, or every 250 service hrs (or monthly)
Remarks	Boost pressure in test run : 1.8 kg/cm ² (at 3200 rpm) If the boost pressure lowers to 1.5 kg/cm ² (at 3200 rpm), clean the inlet.

2) Procedures for cleaning

Step 1

While operating the engine under a normal load (3/4 to 4/4 load), inject detergent using a 50-cc oiler (commercially-available) within approximately 10 seconds.

Step 2

After adding the detergent, wait 3 to 5 minutes to allow dirt to dissolve, and then add 50 cc of water over approximately 10 seconds, using same container container or the like.

Step 3

Do not supply all the volume of detergent or fresh water at once. Otherwise, too much detergent and fresh water may momentarily flow to the turbocharger, and may cause turbine blade fracture or other troubles. Be sure to use the appropriate volume of detergent and fresh water, and conform to the specified injection time.


Step 4

If the air intake pressure or exhaust temperature does not change before and after cleaning, repeat the above cleaning procedures 10 minutes later.

If no change occurs after repeating the cleaning 3 or 4 times, the blower may have been excessively contaminated, or other problems may have occurred. In this case, overhaul and clean the turbo-chager.

Step 5

After cleaning, operate the engine under a normal load for at least 15 minutes to dry the turbo-charge.



3) Checking the connection parts

For details on checking the connection part, refer to Sec. 3 "Precautions" ; No.12.

Inspection schedule	Daily
---------------------	-------

4) Checking operation of the major parts

Consult the nearest YANMAR dealer.

Inspection schedule	Every 2500 service hrs
---------------------	------------------------


9. EASY TROUBLESHOOTING GUIDE

9-1 Air Is Mixed in Fuel System


The fuel system includes the fuel tank, water separator, fuel oil filter, feed pump, fuel injection pump, high pressure pipe and fuel injection valve.

If air enters this system, fuel oil cannot be injected. Completely bleed air from the fuel system by using the following procedure:

- (1) Set the regulator lever to the NORMAL position.
- (2) Open all the shut-off valves of the fuel system.
- (3) Loosen the air vent bolt of the fuel injection pump.



- (4) Operate the priming pump attached to the side of the fuel pump. (Turn the knob counterclockwise, and the piston of the priming pump will move up and down.) Pump the knob at least 10 times or until the air completely purged. Also push the knob of the priming pump down and then turn clockwise to lock it.
- (5) Loosen the cap nut of the high-pressure fuel pipe. While turning the flywheel by running the starting motor, check that fuel flows out of the cap nut portion, and then tighten the cap nut. Repeat this procedure for all cylinders.



- (6) After bleeding air from all the cylinders, turn the flywheel, and check that fuel is being injected by the sound Brr! Brr! the injectors generate.

9-2 Pressures of Engine Lube Oil Is Abnormal

The engine lube oil pressure has been factory-adjusted before shipping. Normally, you need not readjust it. However, if the lube oil pressure is not normal (4.5 to 5.5 kg/cm² at 3000 rpm) or if the LUB-OIL PRESS alarm lamp does not go out, consult the nearest YANMAR dealer.

9-3 Fresh Water Temperature Is Abnormally High

If the fresh water temperature exceeds 90°C, the following problems may be affecting the fresh water system or seawater system.

- (1) The fresh water passage is blocked due to failure of the fresh water pump or clogging of the fresh water passage.
- (2) Fresh water does not circulate through the cooler due to malfunction of the thermostat.
- (3) The flow rate of fresh water is reduced due to failure of the seawater pump or clogging of the seawater passage.
- (4) Fresh water is not cooled due to contamination of the cooler. In this case, consult the nearest YANMAR dealer.

9-4**Marine Gear Oil Pressure is
Abnormal (Yanmar Marine Gear)**

The clutch oil pressure has been factory-adjusted before shipment.


However, if the clutch should slip due to low oil press, temporarily tighten the emergency bolt. This will allow the boat to go forward.

For details on the emergency bolt, refer to Sec. 7-4.


The LUB-OIL PRESS alarm lamp may light when the engine speed is rapidly reduced.

10. SYSTEM DIAGRAMS


1) Fuel oil system diagram




2) Cooling water system diagram



3) Lube oil system diagram



4) B2-type instrument panel



YANMAR DIESEL ENGINE CO.,LTD.



OVERSEAS OPERATIONS DIVISION

1-1, 2-chome, Yaesu, Chuo-ku, Tokyo 104, Japan

Telex: 0222-4733

Telephone: 03-3275-1111

Faxsimile: 03-3272-0687 Cable: YANMAR TOKYO

User's record

Date of purchase

Place of purchase (Name of dealer)